

# Doors™ v4.55

---

## 1.0 Doors

### 1.1 Doors v4.55

Doors v4.55 releases the following improvements.

1. When performing a “Save Report to File” or “Print” operation in Formatted Reports, the processing speed has been increased to allow for quicker performance. The “View Report on Screen” processing speed was increased in an earlier release.
2. An additional report has been added to the Formatted Reports. “Date of Last Card Used” will display a list of the last time a credential was used at a given site. This will allow an operator to determine if a card has not been used for an extended period of time.

## 2.0 Compatibility

Doors software only supports PXL-250, PXL-500, PXL-510, EntraGuard Gold, EntraGuard Titanium, and EntraGuard Platinum controllers. For proper operation of Doors v4.55 software, the following controller requirements must be met.

*NOTE: For all controllers, you can use downlevel firmware revisions, but if the controller firmware does not meet minimum revision levels listed below, new program features will not be available for use as these features are not implemented in the downlevel firmware releases.*

### For PXL-500 Only Networks

- For complete software/firmware compatibility, Doors v4.55 software must be used with PXL-500 controllers using firmware revision 8.4.46 or higher.
- For complete software/firmware compatibility, Doors v4.55 software must be used with PXL-510 controllers using firmware revision 8.4.46 or higher, and PIC v2.11 or higher.
- In Alarm Control applications, a PXL-510 MUST be the master controller.

### For EntraGuard Only Networks

- For complete software/firmware compatibility, Doors v4.55 software must be used with EntraGuard Gold and EntraGuard Titanium controllers using firmware revision 7.3.16 or higher, and PIC release 1.03 or higher.
- For complete software/firmware compatibility, Doors v4.55 software must be used with EntraGuard Platinum controllers using firmware revision 9.0.2 or higher, and PIC16 v1.0.10 and PIC18 v1.0.1 or higher.

### For PXL-250 Only Networks

- For complete software/firmware compatibility, Doors v4.55 software must be used with PXL-250 controllers using firmware revision 6.3.20 or higher.



### For Mixed Controller Type Networks (mixing PXL-500s, PXL-250s, and/or EntraGuard)

- To use the Alarm Control feature, a PXL-510 must be the master controller on the network.
- To use the Temp Cards feature, a PXL-500 or PXL-510 controller must be the master controller on the network.
- A PXL-500 or PXL-510 may be used as a slave controller on a network with a PXL-250 master controller, however features that require a PXL-500 or PXL-510 to be the master controller (e.g. Temp Users and Alarm Control) will not be available.
- A PXL-500 or PXL-510 may be used as a slave controller with an EntraGuard Gold, EntraGuard Titanium, or EntraGuard Platinum as the master controller.
- In a mixed network of PXL-250s and EntraGuard Gold, EntraGuard Titanium, or EntraGuard Platinum controllers, an EntraGuard controller must be the master controller in the network. There is no such requirement in a mixed network of PXL-500s or PXL-510s and EntraGuards.

### For Badging

- GuardDraw software v5.3 contained within this release is compatible with *Doors* v3.74 or later releases only.

*NOTE: For specific compatibility information, refer to the Series 3 and 4 Compatibility Guide (P/N 01876-001).*

## 3.0 The Keri CD-ROM Autorun Program

The Keri CD-ROM has an autorun program that opens a menu which allows you to easily locate all installation programs, and technical and marketing documentation stored on the Keri CD. Insert the CD into your computer.

- If your host computer's autorun feature is enabled, the autorun menu appears.
- If the autorun feature is not enabled, use Windows™ Explorer to browse the Keri CD. Locate and start the “autorun.exe” program to open the autorun menu.

## 4.0 Product Documentation

The Keri CD-ROM includes copies of technical and marketing documentation in Adobe Acrobat® PDF format. The autorun menu includes links to the major documentation sections of the Keri CD. All documentation is stored in Adobe's PDF format, and can be viewed using the Adobe Acrobat Reader program. The Adobe PDF format is a universal document display format that allows you to view and print copies of documents. The autorun menu includes a link to the free Adobe Acrobat Reader installation program on Adobe's web site.

*NOTE: The documents on the Keri CD are the current revisions at the time of CD release. However, these documents are subject to change at any time. If necessary, please contact Tech Support at Keri Systems or view the Technical Documentation Downloads section of the Keri web page to verify the current revision of any document ([www.kerisys.com/pages/download/techdocs.asp](http://www.kerisys.com/pages/download/techdocs.asp)).*

End of document.