NXT-WI Wiegand-Only RIM Installation Drawing Reader LED Configuration D1 - Single-line, three color LED **Reader Type** (firmware default) Wiegand Reader - D5 D2 - Dual-line, three color LED (downloadable firmware) **J**2 D3 - Single-line, two color LED RS-485 Comm - D8 (not supported at this time) J2 Jumper Settings for Reader Power 12VDC 5VDC 2345678 D10 - 12VDC **Reader Power** Selected Wiegand Reader Single-Line LED **Dual-Line LED** * Please refer to the reader * Farpointe * Farpointe Pin# Connection Connection manufacturer's documentation Wire Color Wire Color for other Wiegand reader types. 1 n/a n/a n/a n/a Blue 2 Beeper Blue Beeper 3 LED **Red LED** Brown Brown 4 n/a n/a **Green LED** Orange 5 + 12 VDC Red + 12 VDC Red 6 Black & Shield Black & Shield Ground Ground 7 Data0 Green Data0 Green P/N:02509-002 Rev. B

White

8

Data1

White

Data1